

### ATTENZIONE - ATTENTION - ACHTUNG

- Per lo smontaggio degli utensili utilizzare sempre la chiave di contrasto come indicato nel manuale d'uso.
- For disassembly of the tools use always the contrast key as mentioned in the user instructions.
- Fuer das Abmontieren der Werkzeuge immer den Gegenschlüssel benutzen wie in der Bedienungsanleitung erwaeht.


- Chiave inclusa
- Key included
- Schluessel inbegriffen

Cod. MT	Mandrino Spindle Spindel	I	RPM	Coppia Max Max Torque Max Drehmoment	Reversibile lato mandrino/contromandrino Reversible sub/main spindle side Umkehrbare Spindel-seite/ Gegenspindel-seite	Lubr.interna Coolant through Innenkuehlung	Lubr.esterna Ext. coolant Aussenkuehlung	A	B	CHIAVI NON INCLUDE Keys not included Schluessel nicht einbegriffen	
TKW 1010125	ER25	1:1	6000	40Nm	X	-	X	88.4	55.5	CHSTER25	MNZ0410005 ▪
TKW 1010225	ER25	1:1	6000	40Nm	X	P=70bar	X	88.4	68	CHSTER25	MNZ0410005 ▪
TKW 1010132	ER32	1:1	6000	40Nm	X	-	X	91.4	55.5	CHSTER32	MNZ0410005 ▪
TKW 1010232	ER32	1:1	6000	40Nm	X	P=70bar	X	91.4	68	CHSTER32	MNZ0410005 ▪

TAKISAWA  
MOD: TM2000 12ST.

MODULO MOTORIZZATO ASSIALE H=85mm  
Axial driven tool H=85mm  
Axial angetriebenes Werkzeug H=85mm

Subject to change without notice.



**M.T. srl**

Via Casino Albini 480  
Tel. 0541/956034-957884  
Fax 0541/956341  
47842 S. GIOVANNI IN M. (RN)  
e-mail: mtma@mtmarchetti.com  
http://www.mtmarchetti.com



PAGINA TKW 150-9-10